



RCA
unbal.



XLR
bal.



Use A Control software to reset internal parameters to factory default values

100-240 VAC
50/60 Hz



Switched-mode
Power Supply

Power-up
Mute

Treble

Midrange
A77H &
A8H only

Bass

Bass
A44H &
A77H only

A SERIES



ADAM AUDIO